

Installation Instructions

for a hard frame waterbed

Waterful Wonderbeds
3524 Camp Robinson Road
North Little Rock, AR 72118
501.753.9699

www.wwbeds.com
www.poggyskids.com

Step 1

Place all four frame boards on the floor finish side down and finish edge out as shown below.



Step 2

Place a mark on each of the side boards at 84" and 85 1/2" from the foot of the side board.



Step 3

Place a bracket flush on each end of the back board (the board finished only on the top).
And a bracket on the foot end of each side board using 3 - 1 1/2" screws for each bracket



Step 4

Attach a side board to the foot board using 3-1 ½” screws. Repeat for the other side.



Step 5

Attach the dummy headboard to the sideboards between the marks made in step 2. The frame is now assembled and should resemble a rectangle. Place the frame exactly where it needs to be in the room. This is widest and longest part of the bed.



Step 6

Assemble the pedestal inside the frame. If a basic pedestal is used go to step 6-A. If drawer unit is used go to step 6-B.

6-A. Not shown. Place the four boards inside the frame (the unfinished board should go at the head of the bed) attach each corner together with extrusions. Place the supports in the center of the pedestal, they should form an "X".

6-B. Shown. Drawers are divided into two sections. Place each section on each side of the bed. For supersingle slide the units together. For a king or queen a divider is slid in between the units. The finished boards go to the head and foot. The other ones go in the center.



Step 7

After the frame and pedestal are squared and the space is divided evenly between the pedestal and frame, lift the frame out of your way, onto its side.



Step 8

Place the decking down on top of the pedestal and line it up with the grooves in the footboard and headboard of the frame.



Step 9

Pull the frame back down onto the decking, making sure the decking rides in the grooves of the frame.



Step 10

Attach the sideboard to the decking using 2 “L” brackets and ½” screws on each side. The brackets should be placed about 1/3 of the way from the head and 1/3 from foot. Make sure the frame overhangs the pedestal evenly each side. If not frame should be moved over until it is even.



Step 11

Place heater down on top of decking. Run the cord through the notch cut in the decking. Do not place heater over seam of decking. Attach controller to side of the frame. Run the copper wire through the notch and keep it least 12” away from heating pad. For more information see heater instructions.

Step 12

Put safety liner in the frame.

Step 13

Place Mattress in the frame with the valve at the foot. Make sure it is straight, by pulling the corner into place. You may need someone to get in the opposite corner to pull against you.



Step 14

Fill mattress with a waterbed fill kit. Continue pulling the corners until there is a couple inches of water in the mattress. See fill kit instructions for more information.



Step 15

Have a wonderful nights sleep on your Waterful Wonderbed.

